

Converter LUA API Documentation V1.3 (October 2019)

API Functions Description

api.ledControl(color, state)

This function turns on or off the on board LED. It can be used for debugging purposes.

Arguments

color (integer) - The color of LED to control: 0 for *red*, 1 for *green* and 2 for *blue*

state (integer) - The new state of the LED: 1 for *on* and 0 for *off*

example:

```
api.ledControl(2,1) --turns on blue LED
```

api.delayms(ms)

This function makes the execution be paused for *ms* milliseconds.

Arguments

ms (integer) - The number of milliseconds to delay

example:

```
api.delayms(1000) --delay one second
```

tick = api.getTick()

This function returns current number of milliseconds since startup. Counts up to 2^{32} and then restarts from 0.

Returns

tick (integer) - Number of milliseconds since startup of the device

example:

```
--get a timestamp, can be used for timing
```

```
timestamp = api.getTick()
```

data,error,acked,wake,intArg = api.getGUIContext()

This function returns context provided by GUI configuration, if LoRaWAN is used.

Returns

data (string) - Data received using parsing table configured by GUI tool

error (integer) - Zero on success, positive value indicates line number from the request table defined by GUI, which caused the error

acked (integer) - According to GUI, data should be sent using acknowledged (1) or non-acknowledged (0) LoRa transport

wake (integer) - Number of minutes, according to GUI, the device should sleep using `wakeUpIn()` function.

intArg (integer) - Used with SO callback `onThreshold()`, contains the number of SO input, which raised the event.

example:

```
--get context provided by GUI configuration
```

```
data,error,acked,wake = api.getGUIContext()
```

```
data,error,proto,wake,ip,port,intArg = api.getGUIContext()
```

This function returns context provided by GUI configuration, if NB-IoT is used.

Returns

data (string) - Data received using parsing table configured by GUI tool

error (integer) - Zero on success, positive value indicates line number from the request table defined by GUI, which caused the error

proto (integer) - Zero if UDP protocol is used, one if TCP is used

wake (integer) - Number of minutes, according to GUI, the device should sleep using `wakeUpIn()` function.

ip (string) - String with NB-IoT host IP address

port (integer) - NB-IoT host port number

intArg (integer) - Used with SO callback `onThreshold()`, contains the number of SO input, which raised the event.

example:

```
--get context provided by GUI configuration
```

```
buf, err, proto, wake, ip, port = api.getGUIContext()
```

```
num = api.getUniqueNumber()
```

This function returns an unique integer number in range <0; 2³²>.

Returns

num (integer) - Unique number

example:

```
--get an unique number
```

```
num = api.getUniqueNumber()
```

value = api.getVar(index)

This function returns persistent variable value, can be used between different wake up iterations.

Arguments

index (integer) - Index of the variable to read, 0 to 15 is available for RAM variables (lost on reset), 16 to 47 for High Endurance EEPROM (HEE) variables (6.4M writes) and 48 to 1071 is available for variables stored in EEPROM (100k writes).

Returns

value (integer) - Value of the 32bit variable

example:

```
--get persistent variable value from index 1000  
  
--can be used to send different data between wake-ups  
  
--for variables persistent between device reset,  
  
--use indexes 48 to 1071  
  
slotNumber = api.getVar(1000)
```

api.setVar(index, value)

This function saves a persistent variable value, can be used between different wake up iterations.

Arguments

index (integer) - Index of the variable to read, 0 to 15 is available for RAM variables (lost on reset), 16 to 47 for High Endurance EEPROM (HEE) variables (6.4M writes) and 48 to 1071 is available for variables stored in EEPROM (100k writes).

value (integer) - Value to store at *index*

example:

```
--set persistent variable value from index 1000 to value of 3424  
  
--can be used to send different data between wake-ups  
  
--for variables persistent between device reset,  
  
--use indexes 48 to 1071  
  
api.setVar(1000, 3424)
```

api.setVerbosity(verbosity)

This function sets verbosity level.

Arguments

verbosity (integer) - Zero removes all debug printing, verbosity increases up to value of four representing the maximum details

example:

```
--print only critical errors, other print outs are suppressed
```

```
api.setVerbosity(1)
```

```
volt = api.getBatteryVoltage(index )
```

```
This function provides a measured value of battery voltage in millivolts as return value.
```

Returns

```
mv (integer) - Current battery voltage in millivolts
```

```
example:
```

```
--get battery voltage value in mV
```

```
mv = api.getBatteryVoltage()
```

```
status = api.wakeUpAt(day, hour, minute, second)
```

```
This function schedules the next wake up event of the device to provided day of month (day), hour, minute and second. The provided wake up date is therefore absolute and not relative as in wakeUpIn().
```

Arguments

```
day (integer) - Day of month, range 1 to 31
```

```
hour (integer) - Hour, range 0 to 23
```

```
minute (integer) - Minute, range 0 to 59
```

```
second (integer) - Second, range 0 to 59
```

Returns

```
status (integer) - Execution status, 0 for success and -1 for error
```

```
example:
```

```
--schedules next wake up to the 25th, 2:22:58
```

```
status = api.wakeUpAt(25, 2, 22, 58)
```

```
status = api.wakeUpIn(day, hour, minute, second)
```

```
This function schedules the next wake up event of the device after specified time interval. The provided wake up date is therefore relative and not absolute as in wakeUpAt().
```

```
Note: The input arguments are not limited, but the total period specified must not exceed 31 days. (e.g. hour = 40, days = 2 gives a period of 3 days and 16 hours).
```

Arguments

```
day (integer) - Day, range 0 to 31
```

```
hour (integer) - Hour, range 0 to X
```

```
minute (integer) - Minute, range 0 to X
```

```
second (integer) - Second, range 0 to X
```

Returns

`status (integer)` - Execution status, 0 for success and -1 for error

example:

```
--schedules next wake up in 1 day and 122 minutes
```

```
status = api.wakeUpIn(1, 0, 122, 0)
```

`year,month,day,hour,minute,second = api.getTimeDate()`

This function returns current time running in the device. The time can be synchronized using LoRa or debug cable.

Returns

`year (integer)` - Current year

`month (integer)` - Current month

`day (integer)` - Current day of month

`hour (integer)` - Current hour

`minute (integer)` - Current minute

`second (integer)` - Current second

example:

```
--read current date and time
```

```
y,M,d,h,m,s = api.getTimeDate()
```

`api.dumpArray(str)`

This function prints contents of variable as hexadecimal string.

Arguments

`str (string)` - String with variable to be printed

example:

```
--print string "123ef" as hexadecimal
```

```
api.dumpArray("123ef")
```

```
00 : 31 32 33 65 66
```

`result = api.float(operation, format, arg1, arg2)`

This function performs operation on supplied floating point data.

Arguments

`operation (string)` - The operation to perform ("add" - addition, "sub" - subtraction of arg2 from arg1, "mul" - multiplication, "div" - division of arg1 by arg2, "coerce" - coercion, unary operation using only arg1)

format (string) - Two or three characters specifying the format of input/output data. The first position is for arg1 (S - string float representation, e.g. "2.234", B - binary little endian IEEE 754 representation as 4 characters/bytes in a string). The second either specifies the format of arg2 or if last, specifies the format of return data, which are the same adding "N" - coerce and return as little endian integer.

arg1 (string) - The first operation argument, formated as specified in **format**.

arg2 (string) - The second operation argument, formated as specified in **format**.

Returns

result (string, integer) - Returns result of operation, either 4 bytes little endian IEEE 754 float or string float representation or integer value

example:

```
-- Multiply IEE 754 float with a floating point constant and return coerced value
```

```
ret = api.float("mul", "BSN", input, "1000.0")
```

temp = api.ds18b20GetTemp(pwrpin, datapin)

This function returns temperature in Celsius from DS18B20.

Arguments

pwrpin (integer, optional) - Power pin (0 - 3)

datapin (integer, optional) - Data pin (0 - 3)

Returns

temp (integer) - Temperature in Celsius

sak, uid = api.RFID(retry)

This function scans RFID to see UID, SAK, type and data blocks.

Arguments

retry (integer) - Number of possible failed reads from RFID before reading is stopped

Returns

sak (integer) - SAK (Select acknowledge) byte returned from the PICC after successful selection

uid (string) - UID of RFID

api.exec(function)

This function executes specified function by name. Function has to be present in fragments.

Arguments

function (string) - Name of function to be executed

LoRa

```
status, port, answer = api.loraSend(ack, timeout, msg, port)
```

This function sends buffer *msg* to LoRa. Acknowledged or non-acknowledged transport can be used using *ack* parameter. Maximum execution time is limited by *timeout* milliseconds.

Arguments

- ack* (integer) - Selects acknowledged (1) or non-acknowledged (0) transport mode
- timeout* (integer) - The maximum execution time in milliseconds, used in acknowledged mode
- msg* (string) - String to be sent to LoRa
- port* (integer, optional) - Port number

Returns

- status* (integer) - Positive or zero for success, negative for failure
- port* (integer) - Nil or port on which the answer was received
- answer* (string) - Nil or non-zero length string containing gateway answer

example:

```
--sends 0xCCBBAA35 to LoRa with 20s timeout and acknowledged mode  
msg = pack.pack('<b4', 0xCC, 0xBB, 0xAA, 0x35)  
status, port, answer = api.loraSend(1, 20000, msg)
```

```
status = api.loraSetup(class, dataRate, power, ADR)
```

This function sends buffer *msg* to LoRa. Acknowledged or non-acknowledged transport can be used using *ack* parameter. Maximum execution time is limited by *timeout* milliseconds.

Arguments

- class* (string) - Select LoRaWAN class (either A or C)
- dataRate* (integer, optional) - Set data rate: 0 - 7
- power* (integer, optional) - Transmit power: 2, 5, 8, 11, 14 dBm
- ADR* (integer, optional) - Automatic data rate: 0 for off, 1 for on

Returns

- status* (integer) - Positive or zero for success, negative for failure

example:

```
--setup LoRaWAN interface to class A with data rate 0 (SF12), power of 20 dBm and ADR  
off  
status = api.loraSetup("A", 0, 20, 0)
```

```
status, port, buffer = api.loraListenClassC(timeout)
```

This function listens on LoRa with class C until some message is received.

Arguments

timeout (integer, optional) - Timeout of listening in miliseconds, default is 10000 ms

Returns

status (integer) - Positive or zero for success, negative for failure

port (integer) - Communication port

buffer (string) - Message received from LoRa

example:

```
--Listen on LoRa for a message with default timeout of 10 seconds
```

```
status, port, buffer = api.loraListenClassC()
```

```
status, port, buffer = api.loraListenGW(timeout)
```

This function listens on LoRa until GW message is received.

Arguments

timeout (integer, optional) - Timeout of listening in miliseconds, default is 10000 ms

Returns

status (integer) - Positive or zero for success, negative for failure

port (integer) - Communication port

buffer (string) - Message received from LoRa

address (integer) - GW node address

example:

```
--Listen on LoRa for a GW message with default timeout of 10 seconds
```

```
status, port, buffer, address = api.loraListenGW()
```

```
api.loraSetCredentials(devADDR, devEUI, nwsKey, appsKey, appEUI, appKey)
```

This function sets LoRa credentials.

Arguments

devADDR (string) - Device ADDR

devEUI (string) - Device EUI

nwsKey (string) - NWS key

appsKey (string) - APPS key

appEUI (string, optional) - Application EUI

appKey (string, optional) - Application key

example:

```
--Set LoRa credentials  
  
api.loraSetCredentials("22011221", "3333333333333333", "44444444444444444444444444444444", "5555555555555555!  
"70B344440013333")
```

NB IoT

status, answer = api.nbSend(addr, port, msg, timeout, type)

This function sends buffer *msg* to NB on specified IP, port and protocol type. Maximum length of Rx and Tx messages is 512 Bytes. Maximum execution time is limited by *timeout* miliseconds.

Arguments

- addr* (string) - IP address
- port* (integer) - Port
- msg* (string) - String to be sent to NB
- timeout* (integer) - The maximum execution time in milliseconds
- type* (string) - Protocol type, either UDP or TCP.

Returns

- status* (integer) - Zero for success, negative for failure
- answer* (string) - Nil or non-zero length string containing the answer

example:

```
-- sends "test message" string to IP 185.8.239.192 on port 5566 with 6s timeout  
  
status,answer = api.nbSend("185.8.239.192", 5566, "test message", 6000, "UDP")  
  
-- sends buffer to IP and port specified in GUI with 6s timeout  
  
buf, err, proto, wake, ip, port, ctx = api.getGUIContext()  
  
status,answer = api.nbSend(ip, port, "test message", 6000, proto)
```

answer, status = api.nbAT(command, timeout, wakeUp)

This function sends an AT command to NB module with specified timeout.

Arguments

- command* (string) - AT command
- timeout* (integer) - The maximum execution time in miliseconds
- wakeUp* (integer, optional) - Sending 1 will make sure that module is not asleep

Returns

- answer* (string) - Nil or non-zero length string with an answer to a AT command
- status* (integer) - Zero for success, negative for failure

example:

```
-- Get IMSI number of SIM card with timeout of 4 seconds  
res = api.nbAT("AT+CIMI", 4000)
```

MBUS

status, c, a, ci, answer = api.mbusTransaction(msg, timeout, retry=1)

This function transmits *msg* and waits *timeout* milliseconds for the answer. The transmission is retried *retry* times. The *status* contains information about communication status and *c*, *a*, *ci* and *answer* contains MBus answer data. Turn on MBus using **mbusState** first.

Arguments

- msg* (string) - Message to send to MBus
- timeout* (integer, optional) - The maximum time in milliseconds to wait for MBus device answer
- retry* (integer, optional) - Optional number of retransmissions, defaults to 1

Returns

- status* (integer) - Number of bytes received, zero on failure
- c* (integer) - MBus c frame field
- a* (integer) - MBus a frame field
- ci* (integer) - MBus ci frame field
- answer* (string) - MBus frame payload received from the bus

example:

```
--sends MBus frame [0x10, 0x50, 0x30, 0x16], waits 5s for answer twice  
msg = pack.pack('<b4', 0x10, 0x50, 0x30, 0x16)  
status,c,a,ci,ans = api.mbusTransaction(msg, 5000, 2)
```

api.mbusSetup(baudrate, parity, stopBits, dataBits)

This function configures the MBus communication interface. By default, the configuration from GUI is used, but this can be overridden using this API. Turn on MBus using **mbusState** after setting up MBus parameters using this function.

Arguments

- baudrate* (integer, optional) - Baudrate to use for communication (up to 921600 baud)
- parity* (integer, optional) - Parity, 0 for none, 1 for odd and 2 for even parity
- stopBits* (integer, optional) - Number of stop bits, 1 or 2 allowed
- dataBits* (integer, optional) - Number of data bits, 7 or 8 allowed

example:

```
--setup MBus interface to 9600 Baud, 8E2  
  
api.mbusSetup(9600, 2, 2, 8)  
  
api.mbusState(state)
```

This function turns on the MBus circuitry, must be used before **mbusTransaction**.

Arguments

state (integer) - New state of MBus circuitry: 0 for off, 1 for on (apprx 30s power-up)

example:

```
api.mbusState(1) --turn on MBus
```

RS485

```
api.rs485Send(msg)
```

This function sends *msg* to RS485 bus. Turn on RS485 using **rs485State** first.

Arguments

msg (string) - Data to be sent to RS485 bus

example:

```
api.rs485Send('test') --sends 'test' string to RS485
```

```
api.rs485Setup(baudrate, parity, stopBits, dataBits)
```

This function changes the configuration of RS485 interface

Arguments

baudrate (integer, optional) - Baudrate to use for communication (up to 921600 baud)

parity (integer, optional) - Parity, 0 for none, 1 for odd and 2 for even parity

stopBits (integer, optional) - Number of stop bits, 1 or 2 allowed

dataBits (integer, optional) - Number of data bits, 7 or 8 allowed

example:

```
--setup RS485 interface to 9600 Baud, 8E1
```

```
api.rs485Setup(9600, 2, 1, 8)
```

```
api.rs485State(state)
```

This function turns on the RS485 circuitry, must be used before **rs485Send** or **rs485Receive**.

Arguments

state (integer) - New state of RS485 circuitry: 0 for off, 1 for on (fast power-up)

example:

```
api.rs485State(0) --turn off RS485

answer,len = api.rs485Receive( timeout)

This function waits timeout milliseconds for data reception from RS485 bus. Turn on RS485 using
rs485State first.

Arguments

timeout (integer) - The maximum time in milliseconds to wait for RS485 device answer

Returns

answer (string) - Data received from RS485 bus in given time

len (integer) - Number of bytes received

example:

--waits 1s for answer from RS485 bus

ans,len = api.rs485Receive(1000)

crc = api.modbusCrc( msg)

This function calculates Modbus request checksum.

Arguments

msg (string) - Modbus request

Returns

crc (string) - Modbus crc for request

example:

--calculate checksum for Modbus request 110100010002

req = pack.pack('<b6', 0x11,0x01,0x00,0x01,0x00,0x02)

crc = api.modbusCrc(req) --crc = "EE9B"
```

NVT

```
msg, answer = api.nvtProcess(buf)

This function processes NVT message and either sets baudrate, datasize, parity or stop size for MBUS
or MODBUS.

Arguments

buf (string) - Message to be processed

Returns

msg (string) - Message without NVT sequence

answer (string) - NVT answer
```

example:

```
ret, port, buf = api.loraSend(0, 1000, data)

if buf ~= nil then

buf, nvtans = api.nvtProcess(buf)

api.rs485Send(buf)

end
```

answer = api.nvtEncode(msg)

This function encodes message to NVT format.

Arguments

msg (string) - Message to be encoded to NVT

Returns

answer (string) - NVT message

example:

```
ans, len = api.rs485Receive(50)

ans = api.nvtEncode(ans)

api.loraSend(0, 1, ans)
```

Dali

api.daliTransaction(command, address, isDirect)

This function transmits Dali command to specified address.

Arguments

command (integer) - Dali command

address (integer, optional) - Address to

isDirect (integer, optional) - 1 if message is direct, 0 if not

Returns

answer (integer) - Nil or non-zero if an answer has been received from Dali device (when non direct transmission is used)

example:

```
-- initialize Dali device

ans = api.daliTransaction(0xA500)
```

S0

api.S0setThreshold(channel, value)

This function defines a threshold between current value of a S0 channel counter and last reported value. When the difference of these last two reaches the *value*, the `onThreshold()` event is called.

Arguments

channel (integer) - Number of the S0 channel, 0 to 3.

value (integer) - Threshold value, 0 disables the threshold, 0x1-0xFFFFFFFF sets the threshold.

example:

```
--sets threshold for channel 2 to the value of 10000
```

```
api.S0setThreshold(2, 10000)
```

api.S0initializeCounter(channel, value)

This function is typically used on startup to restore current value of the S0 counter from a non-volatile memory

Arguments

channel (integer) - Number of the S0 channel, 0 to 3.

value (integer) - Value of the S0 counter

example:

```
--sets counter value for channel 0 to the value of 100
```

```
api.S0initializeCounter(0, 100)
```

value = api.S0readCounter(channel)

This function reports the current value of the S0 channel counter specified in the *channel* input argument.

Note: By calling this function, an internal shadow variable for the channel counter is updated, so that the counter for `onThreshold()` event is reset.

Arguments

channel (integer) - Number of the S0 channel, 0 to 3.

Returns

value (integer) - Value of the S0 counter

example:

```
--reads the value of S0 channel 3 and stores to val variable
```

```
val = api.S0readCounter(3)
```

Wireless MBUS**status = api.wmbusSetup(power, role, mode)**

This function changes the configuration of W-MBUS.

Arguments

`power` (integer) - W-MBUS power: -20 dBm, -10 dBm, 0 dBm, 5 dBm, 9 dBm

`role` (string) - W-MBUS role: master, slave, meter, concentrator, repeater

`mode` (string) - W-MBUS mode: S1, S2, T1, T2, T1_C, T2_C, R

Returns

`status` (integer) - Positive or zero for success, negative for failure

example:

```
--setup W-MBus interface to power of 9 dBm, role master/concentrator and T2 mode
```

```
api.wmbusSetup(9, "master", "T2")
```

```
status = api.wmbusSetCField(c_field)
```

This function sets W-MBUS C field.

Arguments

`c_field` (integer) - W-MBUS C field (max value 255)

Returns

`status` (integer) - Positive or zero for success, negative for failure

example:

```
-- Set W-Mbus C field as 128
```

```
api.wmbusSetCField(128)
```

```
status = api.wmbusSetHeader(manid, id, version, devtype)
```

This function sets W-MBUS header.

Arguments

`manid` (integer) - Manufacturer ID, max value 0xffff

`id` (integer) - ID of W-MBUS device (32 bit)

`version` (integer) - Version fiels, max value 0xff

`devtype` (integer) - Device version field, max value 0xff

Returns

`status` (integer) - Positive or zero for success, negative for failure

example:

```
-- Set W-Mbus header for specific device
```

```
api.wmbusSetHeader()
```

```
status = api.wmbusSendFrame(ci, data)
```

This function sends frame through W-MBUS.

Arguments

ci (integer) - CI field

data (string) - Frame to be sent

Returns

status (integer) - Positive or zero for success, negative for failure

example:

```
-- Send W-MBUS frame
```

```
api.wmbusSendFrame(212, "foobar")
```

```
status, c_field, manid, id, version, devtype, ci, payload = api.wmbusReceiveFrame(timeout)
```

This function waits *timeout* milliseconds for data reception from W-mbus.

Arguments

timeout (integer) - The maximum time in milliseconds to wait for RS485 device answer

Returns

status (integer) - Positive or zero for success, negative for failure

c_field (integer) - W-MBUS C field (max value 255)

manid (integer) - Manufacturer ID, max value 0xffff

id (integer) - ID of W-MBUS device (32 bit)

version (integer) - Version fiels, max value 0xff

devtype (integer) - Device version field, max value 0xff

ci (integer) - CI field

payload (string) - Received frame payload

example:

```
-- Receive W-MBUS data with 2000 ms timeout
```

```
status, cfield, manid, id, ver, devtype, ci, payload = api.wmbusReceiveFrame(2000)
```

```
status, c_field, manid, id, version, devtype, ci, payload = api.wmbusSendReceiveFrame(ci, payload, debugon)
```

This function is only available for W-mbus in meter role.

Arguments

ci (integer) - CI field

payload (string) - Payload to be send

||| debugon (integer) - If 1, then debug prints of wmbus frame will be present in stdout

||| **Returns**

||| status (integer) - Positive or zero for success, negative for failure

||| c_field (integer) - W-MBUS C field (max value 255)

||| manid (integer) - Manufacturer ID, max value 0xffff

||| id (integer) - ID of W-MBUS device (32 bit)

||| version (integer) - Version fiels, max value 0xff

||| devtype (integer) - Device version field, max value 0xff

||| ci (integer) - CI field

||| payload (string) - Received frame payload

status, c_field, manid, id, version, devtype, ci, payload = api.wmbusReceiveSendFrame(ci, payload, timeout)

||| This function is only available for W-mbus in concentrator role. It waits *timeout* milliseconds for data reception from W-mbus.

||| **Arguments**

||| ci (integer) - CI field

||| payload (string) - Payload to be send

||| timeout (integer) - The maximum time in milliseconds to wait for RS485 device answer

||| **Returns**

||| status (integer) - Positive or zero for success, negative for failure

||| c_field (integer) - W-MBUS C field (max value 255)

||| manid (integer) - Manufacturer ID, max value 0xffff

||| id (integer) - ID of W-MBUS device (32 bit)

||| version (integer) - Version fiels, max value 0xff

||| devtype (integer) - Device version field, max value 0xff

||| ci (integer) - CI field

||| payload (string) - Received frame payload

DIO

status = **api.DIOWaitForEvent(pin, event, sync, timeout)

||| This function waits for specified event on certain pin.

||| **Arguments**

||| pin (integer, optional) - Pin number 0-3

event (integer, optional) - Event to wait for: 0 - unregister, 1 - rising, 2 - falling, 3 - both

sync (integer, optional) - If 1, then sync event is requested

timeout (integer, optional) - The maximum time in milliseconds to wait

Returns

status (integer) - Positive for success, negative for failure, zero means that event has been unregistered from pin.

`state = api.DIOreadPin(pin)`

This function reads pin state.

Arguments

pin (integer, optional) - Pin number 0-3

Returns

state (integer) - 1 if pin is set, 0 if not.

`status = api.DIOWritePin(pin, state)`

This function writes pin state.

Arguments

pin (integer, optional) - Pin number 0-3

state (integer, optional) - Pin state: -1 - high impedance, 0 - low, 1 - high

Returns

status (integer) - Zero for success, negative for failure

Example Scripts

Default Script

To be used with the GUI based configuration of the device. A basic error handling is provided and the device wakes up as defined per GUI.

```
function onWake ()  
  
buf,err,ack,intArg = api.getGUIContext()  
  
  
if err ~= 0 then  
  
print("Error occurred on line" .. tostring(err))  
  
print("Sending error code to LORA")  
  
api.loraSend(ack,20000,tostring(err))
```

```
    print("Done sending")

    else

        print("Sending to LORA")

        api.loraSend(ack,20000,buf)

        print("Done sending")

        print("No error, sent to lora")

    end

    api.wakeUpIn(0,0,wake,0)

end

function onStartup()

    print("Starting up LUA interface...")

end
```

Script with time slots

This script sends two different MBus requests to two different devices at two different baud rates. The two devices share the same MBus. To be compliant with LoRa transmission duty cycle, each device is read out in its own time slot. Furthermore, the battery voltage information is sent every third time slot.

```
function onWake ()

buf,err,ack,wake,intArg = api.getGUIContext()

state = apigetVar(0)

if state == 0 then

    api.mbusSetup(2400, 2, 1, 8)

    api.mbusState(1)

    status, ans = api.mbusTransaction(

        pack.pack('<b5', 0x10,0x12,0x34,0x56,0x16),

        4000, 1)

    api.mbusState(0)

    state = 1
```

```

elseif state == 1 then

api.mbusSetup(9600, 2, 1, 8)

api.mbusState(1)

status, ans = api.mbusTransaction(
pack.pack('<b5', 0x10,0x78,0x9A,0xBC,0x16),
3000, 2)

api.mbusState(0)

state = 2

else

volt = api.getBatteryVoltage

ans = "Battery: " .. tostring(volt) .. "mV"

wake = 2*wake --sleep twice more time

state = 0

end

print("Sending to LORA")

api.loraSend(ack,20000,ans)

print("Done sending")

api.wakeUpIn(0,0,wake,0)

api.setVar(0,state)

end

function onStartup()

print("Starting up LUA interface...")

end

```

Script for S0 inputs reporting

This script defines a LUA function wordToBuffer() for easy insertion of 32bit integer to a buffer and getS0Data() function, which is used to format a packet containing values from S0 counters and current battery voltage.

A new event is used - onThreshold(), which is called when an S0 channel is incremented by a defined amount of units (here the value is setup to 1000 in the onStartup() callback function). The data frame is sent to LoRa either periodically or when the threshold is hit.

```
function wordToBuffer(word)

local buff = ""

buff = buff .. string.char(word%256) .. string.char((word/256)%256)

buff = buff .. string.char(((word/256)/256)%256)

buff = buff .. string.char(((word/256)/256)/256)%256

return buff

end

-- get and format S0 inputs

function getS0Data()

s00 = api.S0readCounter(0)

print("S0-0: "..tostring(s00))

s01 = api.S0readCounter(1)

print("S0-1: "..tostring(s01))

s02 = api.S0readCounter(2)

print("S0-2: "..tostring(s02))

s03 = api.S0readCounter(3)

print("S0-3: "..tostring(s03))

-- read old values

s00_l = api.getVar(0)

s01_l = api.getVar(1)

s02_l = api.getVar(2)

s03_l = api.getVar(3)

s00_ll = api.getVar(4)

s01_ll = api.getVar(5)

s02_ll = api.getVar(6)

s03_ll = api.getVar(7)

-- update old values
```

```
api.setVar(0, s00)

api.setVar(1, s01)

api.setVar(2, s02)

api.setVar(3, s03)

api.setVar(4, s00_l)

api.setVar(5, s01_l)

api.setVar(6, s02_l)

api.setVar(7, s03_l)

-- get battery voltage

v = api.getBatteryVoltage()

-- assemble the frame

buf = string.char(5) -- device class

buf = buf .. wordToBuffer(s00)

buf = buf .. wordToBuffer(s00_l)

buf = buf .. wordToBuffer(s00_ll)

buf = buf .. wordToBuffer(s01)

buf = buf .. wordToBuffer(s01_l)

buf = buf .. wordToBuffer(s01_ll)

buf = buf .. wordToBuffer(s02)

buf = buf .. wordToBuffer(s02_l)

buf = buf .. wordToBuffer(s02_ll)

buf = buf .. wordToBuffer(s03)

buf = buf .. wordToBuffer(s03_l)

buf = buf .. wordToBuffer(s03_ll)

buf = buf .. string.char(0)

buf = buf .. string.char(v%256) .. string.char((v/256)%256)

buf = buf .. string.char(0)

-- print the frame
```

```
print("Frame in hex: <devClass, S0_0, S0_0_last, ... , 0, voltage, 0>")

api.dumpArray(buf)

return buf

end

function onWake ()
buf,err,ack,wake = api.getGUIContext()

print("onWake(), periodic wake up")

buf = getS0Data()

print("Sending to LORA")

api.loraSend(ack,20000,buf)

print("Done sending")

print("No error, sent to lora")

api.wakeUpIn(0,0,wake,0)

end

function onThreshold ()
buf,err,ack,wake,src = api.getGUIContext()

print("onThreshold(), reason S0: " .. tostring(src))

buf = getS0Data()

print("Sending to LORA")

api.loraSend(ack,20000,buf)

print("Done sending")

print("No error, sent to lora")

end
```

```
function onStartup()

    print("onStartup(), Starting up LUA interface...")

    --set to threshold

    api.S0setThreshold(0, 1000)

    api.S0setThreshold(1, 1000)

    api.S0setThreshold(2, 1000)

    api.S0setThreshold(3, 1000)

    -- initialize old values

    api.setVar(0, 0)

    api.setVar(1, 0)

    api.setVar(2, 0)

    api.setVar(3, 0)

    api.setVar(4, 0)

    api.setVar(5, 0)

    api.setVar(6, 0)

    api.setVar(7, 0)

end
```

Other available LUA API

Math library

This library provides basic mathematic functions, note that for simplicity, lua in this embedded device uses integer and not float arithmetics.

Any function from this library is prepended by "math."

The list of supported functions is: **abs, ceil, floor, max, min, pow, random, randomseed, sqrt**.

For more details and function arguments definition, refer to official Lua 5.1 documentation:
<https://www.lua.org/manual/5.1/manual.html> (Section 5.6, mathematical functions)

Pack library

The pack library is used as a convenient way to parse binary buffers and to create a binary representation of lua variables.

Any function from this library is prepended by "pack".

The list of supported functions is: **pack, unpack**.

For more details and function arguments definition, refer to eLua project pages:
http://www.eluaproject.net/doc/v0.8/en_refman_gen_pack.html#overview

String library

This library can be used for manipulation of string variables and string buffers.

Any function from this library is prepended by "string".

The list of supported functions is: **byte, char, format, len, sub**.

For more details and function arguments definition, refer to official Lua 5.1 documentation:
<https://www.lua.org/manual/5.1/manual.html> (Section 5.4, string manipulation)

Lua base library

This library contains a basic lua 5.1 language library.

The list of supported functions is: **assert, collectgarbage, dofile, error, gcinfo, getfenv, getmetatable, loadfile, load, loadstring, next, pcall, print, rawequal, rawget, rawset, select, setfenv, setmetatable, tonumber, tostring, type, unpack, xpcall**.

For more details and function arguments definition, refer to official Lua 5.1 documentation:
<https://www.lua.org/manual/5.1/manual.html> (Section 5.1, basic functions)

Lua debug library

This library is used for debugging. Any function from this library is prepended by "debug".

List of supported functions is: **debug, getfenv, gethook, getinfo, getlocal, getregistry, getmetatable, getupvalue, setfenv, sethook, setlocal, setmetatable, setupvalue, traceback**.

For more details and function arguments definition, refer to official Lua 5.1 documentation:
<https://www.lua.org/manual/5.1/manual.html> (Section 5.9, the debug library)